



ROSCALATA CABEZA PLANA

Código	Diámetro	Largo "L"	Envase	Díametro "A" Cabeza, mm	Altura "H" Cabeza, mm	Díametro Perf. Piloto	Rango a Roscar (mm)	Torque Instalación (Nm)
--------	----------	-----------	--------	-------------------------	-----------------------	-----------------------	---------------------	-------------------------

Zincado Brillante

02RLP	#4	3/8	100 U	5,3	1,7	2.3 - 2.5	0.4 - 1.5	1,46
03RLP		3/4						
04RLP	#6	3/8	100 U	6,6	2,1	2.7 - 3.0	0.4 - 1.9	2,7
05RLP		1/2						
06RLP		5/8						
07RLP		3/4						
08RLP		7/8						
27RLP	1"							
09RLP	#8	3/8	100 U	7,9	2,5	3.0 - 3.2	0.6 - 1.9	4,4
10RLP		1/2						
11RLP		5/8						
12RLP		3/4						
13RLP		7/8						
14RLP		1"						
28RLP		1 1/4						
24RLP		1 1/2						
26RLP	2"							
15RLP	#10	5/8	100 U	9,2	2,9	3.7 - 4.0	0.5 - 3.2	6,32
16RLP		3/4						
18RLP		1"						
19RLP		1 1/8						
20RLP		1 1/4						
25RLP	1 1/2							
29RLP	2"							
21RLP	#12	3/4	100 U	10,5	3,3	4.3 - 4.8	0.6 - 3.2	9,94
30RLP		1"						
31RLP		1 1/4						
32RLP		1 1/2						
33RLP	2"							
23RLP	1/4	5/8	100 U	12,2	3,9	5.0 - 5.5	0.8 - 4.7	16
34RLP		1"						

Zincado Negro

N04RLP	#6	3/8	100 U	6,6	2,1	2.7 - 3.0	0.4 - 1.9	2,7
N05RLP		1/2						
N06RLP		5/8						
N07RLP		3/4						
N09RLP	#8	3/8	100 U	7,9	2,5	3.0 - 3.2	0.6 - 1.9	4,4
N10RLP		1/2						
N11RLP		5/8						
N12RLP		3/4						
N14RLP		1"						
N24RLP	1 1/2							
N15RLP	#10	5/8	100 U	9,2	2,9	3.7 - 4.0	0.5 - 3.2	6,32
N18RLP		1"						
N20RLP		1 1/4						
N25RLP		1 1/2						

